OKAMPLETE KONTROL M32

BROWSER CONTROL Select a Browser field Scroll Browser tags and Presets Select Browser tag Load selected Preset in Results list Clear Browser tags Set Preset as Favorite in Results list Sort by Favorites in Results list Toggle between User Content and Factory Content **PLUG-IN CONTROL** Control Instrument and Plug-in parameters Navigate Plug-in chain Add Effect Plug-in on empty Plug-in slot Move selected Effect Plug-in left or right in Plug-in chain Select previous/next Preset

Navigate parameter pages



Bypass selected Plug-in in Plug-in chain



Remove selected Plug-in from Plug-in chain





Select track

Select region

Mute/unmute selected Track

Solo/unsolo selected Track

Adjust Track volume

Adjust panorama for selected Track

Undo action Redo action

Quantize to grid value

Toggle automation between Read mode and Touch mode









Tap tempo



Punch in while playback is running

Enable/disable count-in

Stop playback/recording at current position

Relocate playhead position to song start when stopped

Scroll playhead position

Enable/disable loop mode

Move loop by its own length

Enable/disable metronome



Logic/GarageBand

TRANSPORT CONTROL

Start playback

Restart playback

Start recording





EDIT CONTROL









OKAMPLETE KONTROL M32

Ableton Live



Bypass selected Plug-in in



SHIFT

Remove selected Plug-in from Plug-in chain



TRACK CONTROL



Select Clip or Scene Slot

Start/stop selected Clip or

Mute/unmute selected Track

Solo/unsolo selected Track

Adjust panorama for selected







Redo action	SHIFT
Quantize to grid value	QUANTIZE Auto

Toggle automation between Read mode and Touch mode

EDIT CONTROL

Undo action



TRANSPORT CONTROL

Start playback



Enable Clip recording



Start Arranger recording together with playback

Scroll playhead position



Stop playback/recording at current position

Relocate playhead position to song start when stopped

Enable/disable loop mode

Enable/disable metronome



Tap tempo

OKOMPLETE KONTROL M32

MASCHINE

TRANSPORT CONTROL

Start/stop playback	▶ PLAY Restart
Restart playback at the beginning of the Loop Range	SHIFT + PLAY Restart
Enable/disable recording	● REC Count-In
Record with count-in	SHIFT + Count-In
Stop playback/recording	■ STOP
Enable/disable metronome	METRO
Adjust tempo	
Enable/disable loop mode	LOOP
EDIT CONTROL	

)	Enable/disable loop mode	LOOP	
	EDIT CONTROL		
	Undo action	UNDO Redo	
	Redo action	SHIFT	
	Quantize to grid value	QUANTIZE Auto	
	Enable/disable automation	SHIFT	-
	Enable/disable Scale engine	SCALE Edit	
	Edit Scale engine parameters	SHIFT	
	Enable/disable Apeggiator	ARP Edit	
	Edit Arpeggiator parameters	SHIFT	-

Toggle between User Content **PLUG-IN CONTROL**

Control Instrument and Plug-in parameters

Select a Browser field

Select Browser tag

Load selected item in Results list

Clear Browser tags

Sort by Favorites in Results list

and Factory Content

Results list

Set Preset as Favorite in

Presets

Navigate Plug-in chain

Add Effect Plug-in on empty Plug-in slot

Move selected Effect Plug-in left or right in Plug-in chain

Select previous/next Preset

Navigate parameter pages





SHIFT

PLUG-IN CONTROL

Bypass selected Plug-in in Plug-in chain

Remove selected Plug-in from Plug-in chain

IDEAS CONTROL

Select Group

Select Scene

SHIFT

SHIFT

Create new Scene



Create new Pattern



TRACK CONTROL

Select Group

Select another Sound of that Group

Create new Group









